



STEP 1.

Take out the microfiber cloth and camera sponge in retail package..
Place your camera on the camera sponge.

Please make sure your lens surface is cleaned before applying ACMAXX LENS ARMOR UV Filter. Use air blower or microfiber cloth to ensure no dust or finger print on it.



STEP 2.

Use the handle on the package to lift AXMAXX LENS ARMOR up.



STEP 3.

Hold two side of protect film with both hands.
Carefully apply ACMAXX LENS ARMOR on your camera lens.



STEP 4.

Once ACMAXX LENS ARMOR is placed properly, you can press it firmly around the edge of the protector in order to attach the protector on your camera.
Remove the plastic protect sheet.



Enjoy taking pictures!

